COOKTOP PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)

30" GAS FREESTANDING
STANDARD CLEAN RANGE
ELECTRONIC IGNITION



Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	LIT98007137	Instructions Installation
	LIT98007121	Installation Instr (Template)
	LIT98007095	Guide, Use & Care
	LIT98007130	Safer Cooking Tips
	LIT98007032	Tech Sheet
2		Cooktop
	98009677	White
	98009678	Biscuit
	98009676	Black
3		Panel, Manifold
	98009460	Black
	98009461	White
	98009459	Biscuit
4		Knob, Burner (4)
	98006100	Black
	98006102	White
	98008208	Biscuit
6		Grate, Burner (2)
	98009281	Black
	98009283	Gray
7	98004722	Clip, Cooktop (2)
8	98007209	Wire, Ground
9	98004723	Bumper, Cooktop
10	98005000	Screw (3)
11		Cap, Burner
	98003979	Black
	98005754	Gray

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BACKGUARD PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1		Endcap
	98004632	Black Left
	98004633	Black Right
	98005336	White Left
	98005337	White Right
	98008274	Biscuit Left
	98008275	Biscuit Right
2	98006083	Rear, Backguard
3		Swtich, Rocker
	98006392	Black
	98006393	White
	98008276	Biscuit
4		Panel, Backguard
	98006062	Black
	98006063	White
	98008271	Biscuit
5		Timer
	98007080	Black
	98007081	White
	98007155	Biscuit
8	98005000	Screw
9		Bracket, Timer
	98008499	Left
	98008498	Right

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

MANIFOLD PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1		Burner, Top
	98008971	Left
	98003939	Right
2	6610243	Venturi, Front (2)
3	98005500	Brkt., Venturi (4)
4	6610244	Venturi, Rear (2)
5	6610250	Spark Module
6	98005520	Regulator
7	98007192	Cover, Module
8	98003849	Spreader, Flame
9	98006632	Screw
10	98004314	Burner, Oven
11	98006633	Screw
12	98005561	Harness, Switch
13	98011275	Valve, Oven
14	98006633	Screw
15		Valve, Burner (4)
	98005574	9,500 BTU
	98005626	11,500 BTU
16	98005521	Bolt, Valve Mtg
17	98010087	Pipe, Manifold
18	98007127	Sleeve, 3/8"
19	98003984	Thermostat
20	98005663	Bolt, T−Stat Mtg
21	98005652	Igniter, Oven
		Oven Pilot)
23	98011202	Tubing (Regltr to
		Oven Valve)
29	98005516	Fitting, Tube
30	98005506	Fitting, Female
31	98011226	Tubing, Inlet
34	98005659	Screw
35	98004484	Screw
36		Igniter, Top
	98008959	Standard(2)
	98008969	Super Burner(2)
37	98007187	Clip, Igniter

FOLLOWING PARTS NOT ILLUSTRATED

98005979	LP Spud Kit (For Use With LP)
98005982	Natural Spud Kit (For use with Natural Gas)

CHASSIS PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0

(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CHASSIS PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION
1	98003799	Flue Box
2	98006653	Clip, Flue
3	98007195	Shield, Insulation
4		Panel, Side (2)
	98010042	White
	98010045	Biscuit
	98010043	Black
5	98005502	Clip, Oven Bottom
6	98006710	Counterweight
7	98006739	Wire, Brick
8	98005044	Frame, Front
9	98005306	Foot, Front (2)
10	98005307	Foot, Rear (2)
11	98004449	Bottom, Oven
13	98003847	Baffle, Base
14	98003830	Rail, Base (2)
15	98004453	Support, Burner
16		Button, Plug
	98007388	25/32"
	98007390	15/32"
	98007389	5/16"
17	98004723	Bumper (2)
18	98009179	U−Nut
19	98005765	Switch, Door
20	98003809	Back, Main
21	98009174	Seal, Oven
22	98006633	Screw
23	98007193	Washer
24	98007126	Base, Foot
25	98006632	Screw
26	98006715	Shield, Channel
27	98007191	Shield, Lower
28	98006631	Screw
29	6610236	Cord, Power
30	98005026	Clip, Tubing
31	98005713	Retainer, Burner
32	98006633	Screw
33	98004447	Top, Oven
34		Side, Oven
	98004452	Right Hand
	98004451	Left Hand
35	98005768	Back, Oven
36	98010053	Support, Rear
37	98004498	Bulb, Light
38	98004293	Socket, Light
39	98006634	Screw
40	98007205	Cap, Insulation
41	98005641	Sensor, Oven

INSULATION

98004285	Insulation, Wrap
98004294	Tie, Insulation
98004286	Insulation, Back

OVEN & BROILER PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	98011454	Rack, Oven (2)
2	98003480	Grill, Broiler
3	98003479	Pan, Broiler
4	98005297	Rack, Broiler
5	98005296	Bracket, Rack
6		Guide, Fixed(2)
	98004994	Left
	98005209	Right
7		Guide, Mobile(2)
	98004995	Left
	98004954	Right

Illus. No.	Part No.	DESCRIPTION
8		Screw
	98006727	White
	98008169	Biscuit
	98006726	Black
9	98004991	Liner, Door
10	98006209	Storage, Drawer
11	98004056	Insulation, Door
12		Panel, Door
	98009337	White
	98009336	Biscuit
	98009338	Black

Illus. No.	Part No.	DESCRIPTION
13		Handle, Brlr Door
	98006623	White
	98008266	Biscuit
	98006624	Black
14	98004773	Spacer, Handle
15	98004052	Bumper, Door(2)
20	98004219	Screw
21	98006644	Screw

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

DOOR PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)



Illus. No.	Part No.	DESCRIPTION
1	98004218	Screw
3	98010182	Liner, Door
4	98006753	Insulation, Door
5		Clip, Glass
	98004952	Left
	98004953	Right
6	98004734	Hinge, Door (2)
7	98008699	Screw
8		Panel, Door
	98005328	Black
	98005357	White
	98008172	Biscuit
9	98004042	Glass, Inner
10		Handle, Oven Door
	98005317	Black
	98005318	White
	98008164	Biscuit
11	98004650	Nut, Push
12	98004993	Screw
13		Side Trim, Door(2)
	98006793	Black
	98006794	White
	98008174	Biscuit
14		Screw
	98006726	Black
	98006727	White
	98008169	Biscuit
15		Retainer
	98004564	Right
	98004629	Left
16		Lower Trim, Door
	98010187	Black
	98010185	White
	98010184	Biscuit
17	98004219	Screw
18	98004227	Bumper
19	98004938	Insulation, Retainer−Top
20	98004965	Insulation, Retainer−Bottom
21		Top Trim, Door
	98006884	Black
	98006885	White
	98008175	Biscuit
22	98007185	Insulation

MISCELLANEOUS PARTS

For Model: SF315PEKW0, SF315PEKQ0, SF315PEKT0, SF315PEKV0, SF315PEKB0
(White) (Designer White) (Designer Biscuit) (Biscuit) (Black)

Illus. No.	Part No.	DESCRIPTION

Following Parts Not Illustrated

SPLICING WIRES−−25FT. LENGTH

242828	Wire, Black 12 Ga. 150° c
242820	Wire, Black 14 Ga. 150°c
242821	Wire, Blue 14 Ga. 150°c
242822	Wire, Brown 14 Ga. 150°c
242830	Wire, Brown 14 Ga. 200°c
242823	Wire, Green 14 Ga. 150°c
242824	Wire, Orange 14 Ga. 150°c
242829	Wire, Red 12 Ga. 150°c
242825	Wire, Red 14 Ga. 150°c
242831	Wire, Red 14 Ga. 200°c
242826	Wire, White 14 Ga. 150°c
242827	Wire, Yellow 14 Ga. 150°c
242832	Wire, Yellow 14 Ga. 200°c

REFINISHING MATERIAL

799832	Kit, Porcelain Repair (White)
242756	Touch−Up Self−Clean(1/2 Pt)
261582	Grease

INSULATION

261514	Insulation, Fiberglass (1−1/2" x 24" x 120")
240132	Insulation, Fiberglass (2−1/2" x 22" x 120")

PAINT, TOUCH−UP (1/2oz.)

72017	White
72107	Almond
511873	White Porcelain (2 Oz.)

WIRING HARNESS PARTS

98005822	Cord, Power
98005561	Harness, Switch
98005553	Harness, T−Stat
98005896	Clip, Wire
98005915	Clip, Wire
98005894	Clamp, Cord

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350956	Almond
285006	Superior Black
206922	Primer (White)

PAINT, BULK (1 qt.)

799344	White (Uncut)
978883	Almond (Uncut)

ACCESSORY PARTS

241430	Foil, Aluminum Oven (18" x 25')

ANTI−TIP KIT

98007059	Anti−Tip Kit

Miscellaneous

814381	Pin Kit−Dr Removal